



GB QUICK GUIDE FOR THE CONFIGURATION OF VARIABLE SPEED DRIVES

VLG3...



WARNING!

- Carefully read the manual before the installation or use.
- This equipment is to be installed by qualified personnel, complying to current standards, to avoid damages or safety hazards.
- Before any maintenance operation on the device, remove all the voltages from measuring and supply inputs and short-circuit the CT input terminals.
- The manufacturer cannot be held responsible for electrical safety in case of improper use of the equipment.
- Products illustrated herein are subject to alteration and changes without prior notice. Technical data and descriptions in the documentation are accurate, to the best of our knowledge, but no liabilities for errors, omissions or contingencies arising there from are accepted.
- A circuit breaker must be included in the electrical installation of the building. It must be installed close by the equipment and within easy reach of the operator. It must be marked as the disconnecting device of the equipment: IEC/EN/BS 61010-1 § 6.11.3.1.
- Clean the device with a soft dry cloth; do not use abrasives, liquid detergents or solvents.



ATTENTION !

- Lire attentivement le manuel avant toute utilisation et installation.
- Ces appareils doivent être installés par un personnel qualifié, conformément aux normes en vigueur en matière d'installations, afin d'éviter de causer des dommages à des personnes ou choses.
- Avant toute intervention sur l'instrument, mettre les entrées de mesure et d'alimentation hors tension et court-circuiter les transformateurs de courant.
- Le constructeur n'assume aucune responsabilité quant à la sécurité électrique en cas d'utilisation impropre du dispositif.
- Les produits décrits dans ce document sont susceptibles d'évoluer ou de subir des modifications à n'importe quel moment. Les descriptions et caractéristiques techniques du catalogue ne peuvent donc avoir aucune valeur contractuelle.
- Un interrupteur ou disjoncteur doit être inclus dans l'installation électrique du bâtiment. Celui-ci doit se trouver tout près de l'appareil et l'opérateur doit pouvoir y accéder facilement. Il doit être marqué comme le dispositif d'interruption de l'appareil : IEC/EN/BS 61010-1 § 6.11.3.1.
- Nettoyer l'appareil avec un chiffon doux, ne pas utiliser de produits abrasifs, détergents liquides ou solvants.



ACHTUNG!

- Dieses Handbuch vor Gebrauch und Installation aufmerksam lesen.
- Zur Vermeidung von Personen- und Sachschäden dürfen diese Geräte nur von qualifiziertem Fachpersonal und unter Befolgung der einschlägigen Vorschriften installiert werden.
- Vor jedem Eingriff am Instrument die Spannungszufuhr zu den Messeingängen trennen und die Stromwandler kurzschließen.
- Bei zweckwidrigem Gebrauch der Vorrichtung übernimmt der Hersteller keine Haftung für die elektrische Sicherheit.
- Die in dieser Broschüre beschriebenen Produkte können jederzeit weiterentwickelt und geändert werden. Die im Katalog enthaltenen Beschreibungen und Daten sind daher unverbindlich und ohne Gewähr.
- In die elektrische Anlage des Gebäudes ist ein Ausschalter oder Trennschalter einzubauen. Dieser muss sich in unmittelbarer Nähe des Geräts befinden und vom Bediener leicht zugänglich sein. Er muss als Trennvorrichtung für das Gerät gekennzeichnet sein: IEC/EN/BS 61010-1 § 6.11.3.1.
- Das Gerät mit einem weichen Tuch reinigen, keine Scheuermittel, Flüssigreinerer oder Lösungsmittel verwenden.



ADVERTENCIA

- Leer atentamente el manual antes de instalar y utilizar el regulador.
- Este dispositivo debe ser instalado por personal cualificado conforme a la normativa de instalación vigente a fin de evitar daños personales o materiales.
- Antes de realizar cualquier operación en el dispositivo, desconectar la tensión de las entradas de alimentación y medida, y cortocircuitar los transformadores de corriente.
- El fabricante no se responsabilizará de la seguridad eléctrica en caso de que el dispositivo no se utilice de forma adecuada.
- Los productos descritos en este documento se pueden actualizar o modificar en cualquier momento. Por consiguiente, las descripciones y los datos técnicos aquí contenidos no tienen valor contractual.
- La instalación eléctrica del edificio debe disponer de un interruptor o disyuntor. Este debe encontrarse cerca del dispositivo, en un lugar al que el usuario pueda acceder con facilidad. Además, debe llevar el mismo marcado que el interruptor del dispositivo (IEC/EN/BS 61010-1 § 6.11.3.1).
- Limpiar el dispositivo con un trapo suave; no utilizar productos abrasivos, detergentes líquidos ni disolventes.



UPOZORNĚNÍ

- Návod se pozorně pročtěte, než začnete regulátor instalovat a používat.
- Tato zařízení smí instalovat kvalifikovaní pracovníci v souladu s platnými předpisy a normami pro předcházení úrazu osob či poškození věcí.
- Před jakýmkoli zásahem do přístroje odpojte měřicí a napájecí vstupy od napětí a zkratujte transformátory proudu.
- Výrobce nenese odpovědnost za elektrickou bezpečnost v případě nevhodného používání regulátoru.
- Výrobky popsané v tomto dokumentu mohou kdykoli projít úpravami či dalším vývojem. Popisy a údaje uvedené v katalogu nemají proto žádnou smluvní hodnotu.
- Spínač či odpojovač je nutno zabudovat do elektrického rozvodu v budově. Musí být nainstalován v těsné blízkosti přístroje a snadno dostupné pracovníku obsluhy. Je nutno ho označit jako vypínač zařízení přístroje: IEC/EN/BS 61010-1 § 6.11.3.1.
- Přístroj čistěte měkkou utěrkou, nepoužívejte abrazivní produkty, tekutá čistidla či rozpouštědla.



AVVERTIZARE!

- Cititi cu atenție manualul înainte de instalare sau utilizare.
- Acest echipament va fi instalat de personal calificat, în conformitate cu standardele actuale, pentru a evita deteriorări sau pericolele.
- Înainte de efectuarea oricărei operațiuni de întreținere asupra dispozitivului, îndeplățiți toate tensiunile de la intrările de măsurare și de alimentare și scurtcircuitați bornele de intrare CT.
- Producătorul nu poate fi considerat responsabil pentru siguranța electrică în caz de utilizare incorectă a echipamentului.
- Produsele ilustrate în prezentul sunt supuse modificărilor și schimbărilor fără notificare anterioară. Datele tehnice și descrierile din documentație sunt precise, în măsura cunoștințelor noastre, dar nu se acceptă nicio răspundere pentru erorile, omisiunile sau evenimentele neprevăzute care apar ca urmare a acestora.
- Trebuie inclus un disjunctiv în instalația electrică a clădirii. Acesta trebuie instalat aproape de echipament și într-o zonă ușor accesibilă operatorului. Acesta trebuie marcat ca fiind dispozitivul de deconectare al echipamentului: IEC/EN/BS 61010-1 § 6.11.3.1.
- Curățați instrumentul cu un material textil moale și uscat; nu utilizați substanțe abrazive, detergenți lichizi sau solvenți.



ATTENZIONE!

- Leggere attentamente il manuale prima dell'utilizzo e l'installazione.
- Questi apparecchi devono essere installati da personale qualificato, nel rispetto delle vigenti normative impiantistiche, allo scopo di evitare danni a persone o cose.
- Prima di qualsiasi intervento sullo strumento, togliere tensione dagli ingressi di misura e di alimentazione e cortocircuitare i trasformatori di corrente.
- Il costruttore non si assume responsabilità in merito alla sicurezza elettrica in caso di utilizzo improprio del dispositivo.
- I prodotti descritti in questo documento sono suscettibili in qualsiasi momento di evoluzioni o di modifiche. Le descrizioni ed i dati a catalogo non possono pertanto avere alcun valore contrattuale.
- Un interruttore o disgiuntore va compreso nell'impianto elettrico dell'edificio. Esso deve trovarsi in stretta vicinanza dell'apparecchio ed essere facilmente raggiungibile da parte dell'operatore. Deve essere marchiato come il dispositivo di interruzione dell'apparecchio: IEC/EN/BS 61010-1 § 6.11.3.1.
- Pulire l'apparecchio con panno morbido, non usare prodotti abrasivi, detergenti liquidi o solventi.



UWAGA!

- Przed użyciem i instalacją urządzenia należy uważnie przeczytać niniejszą instrukcję.
- W celu uniknięcia obrażeń osób lub uszkodzenia mienia tego typu urządzenia muszą być instalowane przez wykwalifikowany personel, zgodnie z obowiązującymi przepisami.
- Przed rozpoczęciem jakichkolwiek prac na urządzeniu należy odłączyć napięcie od wejść pomiarowych i zasilania oraz zewrzeć zaciski przekładnika prądowego.
- Producent nie przyjmuje na siebie odpowiedzialności za bezpieczeństwo elektryczne w przypadku niewłaściwego użytkowania urządzenia.
- Produkty opisane w niniejszym dokumencie mogą być w każdej chwili udoskonalone lub zmodyfikowane. Opisy oraz dane katalogowe nie mogą mieć w związku z tym żadnej wartości umownej.
- W instalacji elektrycznej budynku należy uwzględnić przełącznik lub wyłącznik automatyczny. Powinien on znajdować się w bliskim sąsiedztwie urządzenia i być łatwo osiągalny przez operatora. Musi być oznaczony jako urządzenie służące do wyłączania urządzenia: IEC/EN/BS 61010-1 § 6.11.3.1.
- Urządzenie należy czyścić miękką szmatką, nie stosować środków ściernych, płynnych detergentów lub rozpuszczalników.



警告!

- 安装或使用前，请仔细阅读本手册。
- 本设备只能由合格人员根据现行标准进行安装，以避免造成损坏或安全风险。
- 对设备进行任何维护操作前，请移除测量输入端和电源输入端的所有电压，并短接 CT 输入端。
- 制造商不负责因设备使用不当导致的电气安全问题。
- 此处说明的产品可能会有变更，恕不提前通知。我们竭力确保本文件中技术数据和说明的准确性，但对于错误、遗漏或由此产生的意外事件概不负责。
- 建筑电气系统中必须装有断路器。断路器必须安装在靠近设备且方便操作人员触及的地方。必须将断路器标记为设备的断开装置：IEC/EN/BS 61010-1 § 6.11.3.1
- 请使用柔软的干布清洁设备；切勿使用研磨剂、洗涤剂或溶剂。



ПРЕДУПРЕЖДЕНИЕ!

- Прежде чем приступать к монтажу или эксплуатации устройства, внимательно ознакомьтесь с содержанием настоящего руководства.
- Во избежание травм или материального ущерба монтаж должен осуществляться только квалифицированным персоналом в соответствии с действующими нормативами.
- Перед проведением любых работ по техническому обслуживанию устройства необходимо обесточить все измерительные и питающие входные контакты, а также замкнуть накоротко входные контакты трансформатора тока (ТТ).
- Производитель не несет ответственность за обеспечение электробезопасности в случае ненадлежащего использования устройства.
- Изделия, описанные в настоящем документе, в любой момент могут подвергнуться изменениям или усовершенствованиям. Поэтому каталожные данные и описания не могут рассматриваться как действительные с точки зрения контрактов.
- Электрическая сеть здания должна быть оснащена автоматическим выключателем, который должен быть расположен вблизи оборудования в пределах доступа оператора. Автоматический выключатель должен быть промаркирован как отключающее устройство оборудования: IEC/EN/BS 61010-1 § 6.11.3.1.
- Очистку устройства производить с помощью мягкой сухой ткани, без применения абразивных материалов, жидких мощных средств или растворителей.



DIKKATI!

- Montaj ve kullanımdan önce bu el kitabını dikkatlice okuyunuz.
- Bu aparatlar kişilere veya nesnelere zarar verme ihtimaline karşı yürürlükte olan sistem kurma normlarına göre kalifiye personel tarafından monte edilmelidir.
- Aparatın (çihaz) herhangi bir müdahalede bulunmadan önce ölçüm girişlerindeki genilimi kesip akım transformatorlerinede kısa devre yaptırınız.
- Üretici aparatın hatalı kullanımından kaynaklanan elektriksel güvenliğe ait sorumluluk kabul etmez.
- Bu dokümanda tarif edilen ürünler her an evrimlere veya değişimlere açıktır. Bu sebeple katalogdaki tarif ve değerler herhangi bir bağlayıcı değeri haiz değildir.
- Binanın elektrik sisteminde bir anahtar veya şalter bulunmalıdır. Bu anahtar veya şalter operatörün kolaylıkla ulaşabileceği yakın bir yerde olmalıdır. Aparatın (çihaz) devreden çıkartma görevi yapan bu anahtar veya şalterinin markası: IEC/EN/BS 61010-1 § 6.11.3.1.
- Aparatın (çihaz) sıvı deterjan veya solvent kullanarak yumaşık bir bez ile siliniz aşındırıcı temizlik ürünleri kullanmayınız.



UPOZORENJE!

- Prije instalacije ili korištenja uređaja, pažljivo pročitate upute.
- Ovaj uređaj mora instalirati, u skladu s važećim normama, obučena osoba kako bi se izbjegle štete ili sigurnosne opasnosti.
- Prije bilo kakvog zahvata na uređaju otpojite napajanje s mjernih i napajajućih ulaza i kratko spojite ulazne stezaljke strujnog transformatora.
- Produđač ne snosi odgovornost za električnu sigurnost u slučaju nepravilnog korištenja opreme.
- Ovdje prikazan uređaj predmet je stalnog usavršavanja i promjena bez prethodne najave. Tehnički podaci i opisi u ovom uputama su točni, ali ne preuzimamo odgovornost za moguće izmjene nenamjerne greške.
- U električnu instalaciju zgrade mora biti instaliran prekidač. On mora biti instaliran blizu uređaja i na dohvata ruke operatera, te označen kao rastavljivač u skladu s normom IEC/EN/BS 61010-1 § 6.11.3.1
- Uređaj čistite s mekom, suhom krpom bez primjene abraziva, tekućina, otapala ili deterđenta.



1. NAVIGATION IN THE MENU
 1.1. Operator panel functions

1842 GB 03 26




The following table lists the names and functions of the keypad's operation keys and LED.

Key	Name	Description
7-Segment Display	SET Indicator	LED flashes during parameter configuration and when the ESC key operates as the multi-function key.
	RUN Indicator	LED turns on (steady) during an operation, and flashes during acceleration or deceleration.
	FWD Indicator	LED turns on (steady) during forward operation.
	REV Indicator	LED turns on (steady) during reverse operation.
	RUN	Used to run the drive
	STOP/RESET	STOP: Stops the drive. RESET: Resets the drive if a fault or failure occurs
	▲, ▼	Switch between codes, or to increase or decrease parameter values.
	MODE/SHIFT	Moves between groups or moves to the digit on the left when setting the parameter. Press the MODE/SHIFT key once again on the maximum number of digits to move to the minimum number of digits.
	ENTER	Switches from the selected state of parameter to the input state. Edits parameter and apply change. Accesses the operation information screen during failure on the failure screen.
	Frequency	Used to set the operation frequency.
	ESC	Operates as ESC key if two keys out of [MODE/SHIFT] key, [▲] key and [▼] key are entered at the same time. – Press ESC in the group navigation mode to go to the initial screen (the frequency display screen). – Press ESC in the mode to change parameter to go to group navigation mode without saving.

1.2. Navigation in the menu

- Codes can be accessed by pressing [▲] and [▼] keys.
- Items can be accessed by pressing [ENT] key.



- Groups can be accessed with the [MODE/SHIFT] key.
- Group access in the other direction can be accessed by pressing the [MODE/SHIFT] key for more than 1sec.
- Parameters can be accessed with [▲] and [▼] keys.
- Press the [ENT] key to change the setting of the parameter.
- Press the [ENT] x2 to save the settings.

The control menu uses the following groups.

The control menu uses the following groups.

Group	Display	Description
Operation	-	Configures basic parameters for drive operation.
Drive (Drive)	dr	Configures parameters for basic operations. These include jog operation, motor capacity evaluation, torque boost, and other keypad related parameters.
Basic (Basic)	bA	Configures basic operation parameters. These parameters include motor parameters and multi-step frequency parameters.
Advanced (Advanced)	Ad	Configures acceleration or deceleration patterns, frequency limits, etc.
Control (Control)	Cn	Configures sensorless vector-related features.
Input Terminal (Input)	In	Configures input terminal-related features, including digital multi-functional inputs and analog inputs.
Output Terminal (Output)	OU	Configures output terminal-related features such as relays and analog outputs.
Communication (Communication)	CM	Configures communication features for RS-485 or other communication options.
Application (Application)	AP	Configures functions related to PID control.
Protection (Protection)	Pr	Configures motor and drive protection features.
Secondary Motor (2nd Motor)	M2	Configures secondary motor related features. The secondary motor (M2) group appears on the keypad only when one of the multi-function input terminals (In.65–In.69) has been set to 26 (Secondary motor).


2. RESET PARAMETERS TO DEFAULT

To reset the parameters of the variable speed drive to the factory values, follow this procedure:

- Press MODE/SHIFT  until dr.0 is displayed.
- With the up and down arrows  , reach parameter dr.93 and set it to value 1.
- Press ENT x2  to save the parameters. Once initialization is complete, dr.93 will be displayed again.

3. COMMAND THE RUN/STOP OF THE MOTOR



3.1. 2-wires control from the flexible I/O terminal block



Parameter	Function	Setting	Description
drv	Command source	1	1=command from terminal block. P1: forward run, P2: reverse run 2= command from terminal block. P1: run command, P2: reverse direction command
In.65	Multifunction input P1	1	Forward command
In.66	Multifunction input P2	2	Reverse command

3.2. 3-wires control from flexible I/O terminal block

Parameter	Function	Setting	Description
drv	Command source	1	Command from terminal block
In.65	Multifunction input P1	1	Forward run
In.66	Multifunction input P2	2	Reverse run
In.69	Multifunction input P5	14	STOP 3-wire control




3.3. From keypad



	Start
	Stop

Parameter	Function	Setting	Description
drv	Command source	0	Keypad

3.4. From RS485 communication port



Parameter	Function	Setting	Description
drv	Command source	3	Run command from built-in RS485 (Modbus-RTU)
CM.01	Serial node	1-250	Modbus serial node
CM.02	Protocol	0	Modbus-RTU
CM.03	Baud rate	3	9600 bps
CM.04	Data format	0	8 data bits, no parity, 1 stop bit

4. FREQUENCY ADJUSTMENT

4.1. From keypad



	Increase frequency
	Decrease frequency

Parameter	Function	Setting	Description
Frq	Frequency setpoint source	1	Frequency adjusted from keypad
dr.19	Minimum frequency	0.0Hz	Insert the value of the minimum frequency
dr.20	Maximum frequency	50.00Hz	Insert the value of the maximum frequency
ACC	Acceleration time	5.0 sec	Insert the value of the acceleration time
dEC	Deceleration time	5.0 sec	Insert the value of the deceleration time


4.2. From integrated front potentiometer



1842 GB 03 26


Parameter	Function	Setting	Description
Frq	Frequency setpoint source	4	Frequency adjusted from integrated front potentiometer
dr.19	Minimum frequency	0.0Hz	Insert the value of the minimum frequency
dr.20	Maximum frequency	50.00Hz	Insert the value of the maximum frequency
ACC	Acceleration time	5.0 sec	Insert the value of the acceleration time
dEC	Deceleration time	5.0 sec	Insert the value of the deceleration time
In.39	Frequency value with front potentiometer at minimum	0%	Frequency value % with front potentiometer at minimum
In.41	Frequency value with front potentiometer at maximum	100%	Frequency value % with front potentiometer at maximum

4.3. From external potentiometer




Parameter	Function	Setting	Description
Frq	Frequency setpoint source	2	Frequency adjusted with voltage analog input V1
dr.19	Minimum frequency	0.0Hz	Insert the value of the minimum frequency
dr.20	Maximum frequency	50.00Hz	Insert the value of the maximum frequency
ACC	Acceleration time	5.0 sec	Insert the value of the acceleration time
dEC	Deceleration time	5.0 sec	Insert the value of the deceleration time
In.01	Maximum frequency value	50Hz	Maximum frequency reachable with potentiometer (with In.11=100%)
In.09	Value of frequency when V1 is at minimum	0%	Minimum frequency value referred to In.01 (0% of 50Hz = 0Hz)
In.11	Value of frequency when V1 is at maximum	100%	Maximum frequency value referred to In.01 (100% of 50Hz = 50Hz)

4.4. From analog input signal type 0-10V




Parameter	Function	Setting	Description
Frq	Frequency setpoint source	2	Frequency adjusted with voltage analog input V1
dr.19	Minimum frequency	0.0Hz	Insert the value of the minimum frequency
dr.20	Maximum frequency	50.00Hz	Insert the value of the maximum frequency
ACC	Acceleration time	5.0 sec	Insert the value of the acceleration time
dEC	Deceleration time	5.0 sec	Insert the value of the deceleration time
In.01	Maximum frequency value	50Hz	Maximum frequency reachable with analog input (with In.11=100%)
In.09	Value of frequency when V1 is at minimum	0%	Minimum frequency value referred to In.01 (0% of 50Hz = 0Hz)
In.11	Value of frequency when V1 is at maximum	100%	Maximum frequency value referred to In.01 (100% of 50Hz = 50Hz)

4.5. From analog input signal type 4-20mA





Analog signal 4-20mA



2-wire sensor with output 4-20mA, supplied with 24VDC

Parameter	Function	Setting	Description
Frq	Frequency setpoint source	5	Frequency adjusted with current analog input I2
dr.19	Minimum frequency	0.0Hz	Insert the value of the minimum frequency
dr.20	Maximum frequency	50.00Hz	Insert the value of the maximum frequency
ACC	Acceleration time	5.0 sec	Insert the value of the acceleration time
dEC	Deceleration time	5.0 sec	Insert the value of the deceleration time
In.01	Maximum frequency value	50Hz	Maximum frequency reachable with analog input (with In.56=100%)
In.53	Minimum I2 input value	4mA	Minimum I2 value = 4mA
In.54	Value of frequency when I2 is at minimum	0%	Frequency value with I2=4mA (0% of 50Hz = 0Hz)
In.55	Maximum I2 input value	20mA	Maximum I2 value = 20mA
In.56	Value of frequency when I2 is at maximum	100%	Frequency value with I2=20mA (100% of 50Hz = 50Hz)

4.6. With preset frequency setpoints




P3 = Preselected frequency selection, first bit
 P3 = Preselected frequency selection, second bit
 P3 = Preselected frequency selection, third bit

P5 (third bit)	P4 (second bit)	P3 (first bit)	Preset frequency activated
Open	Open	Open	No preset frequency activated. The frequency is adjusted by the source set in Frq
Open	Open	Closed	Preset frequency 1
Open	Closed	Open	Preset frequency 2
Open	Closed	Closed	Preset frequency 3
Closed	Open	Open	Preset frequency 4
Closed	Open	Closed	Preset frequency 5
Closed	Closed	Open	Preset frequency 6
Closed	Closed	Closed	Preset frequency 7


Parameter	Function	Setting	Description
dr.19	Minimum frequency	0.0Hz	Insert the value of the minimum frequency
dr.20	Maximum frequency	50.00Hz	Insert the value of the maximum frequency
ACC	Acceleration time	5.0 sec	Insert the value of the acceleration time
dEC	Deceleration time	5.0 sec	Insert the value of the deceleration time
In.67	Multifunction input P3	7	Preselected frequency selection, first bit
In.68	Multifunction input P4	8	Preselected frequency selection, second bit
In.69	Multifunction input P5	9	Preselected frequency selection, third bit
St1	Preset frequency 1	... Hz	Value of preset frequency 1
St2	Preset frequency 2	... Hz	Value of preset frequency 2
St3	Preset frequency 3	... Hz	Value of preset frequency 3
bA.53	Preset frequency 4	... Hz	Value of preset frequency 4
bA.54	Preset frequency 5	... Hz	Value of preset frequency 5
bA.55	Preset frequency 6	... Hz	Value of preset frequency 6
bA.56	Preset frequency 7	... Hz	Value of preset frequency 7

4.7. From motor potentiometer (MOP)



Parameter	Function	Setting	Description
In.67	Multifunction input P3	Up	MOP UP function
In.68	Multifunction input P4	Down	MOD DOWN function
Ad.65	MOP memory	Yes/No	Yes: the frequency set via MOP is saved in the event of run command loss, power-off or alarm. No: in the event of run command loss, power-off or alarm, the drive will restart from 0Hz.
Ad.85	Up/Down Mode	0	When the command is kept pressed, the frequency is increased/decreased continuously.

4.8. From RS485 communication port



Parameter	Function	Setting	Description
Frq	Frequency setpoint source	6	Frequency regulation via built-in RS485 (Modbus-RTU)
dr.19	Minimum frequency	0.0Hz	Insert the value of the minimum frequency
dr.20	Maximum frequency	50.00Hz	Insert the value of the maximum frequency
ACC	Acceleration time	5.0 sec	Insert the value of the acceleration time
dEC	Deceleration time	5.0 sec	Insert the value of the deceleration time
CM.01	Serial node	1-250	Modbus serial node
CM.02	Protocol	0	Modbus-RTU
CM.03	Baud rate	3	9600 bps
CM.04	Data format	0	8 data bits, no parity, 1 stop bit

4.9. PID control

1842 GB 03 26

Parameter	Function	Setting	Description
AP.01	PID enable	2	PID function enabled
AP.20	PID setpoint source	0-6	0 = keypad 1 = V1 voltage analog input 3 = integrated front potentiometer 4 = I2 current analog input 5 = RS485
AP.21	PID feedback source	0-5	0 = V1 voltage analog input 2 = integrated front potentiometer 3 = I2 current analog input 4 = RS485
AP.29	Maximum frequency	50.00Hz	Insert the value of the maximum frequency
AP.30	Minimum frequency	30.00Hz	Insert the value of the minimum frequency
AP.37	PID sleep mode: delay time	... s	PID sleep mode is activated when the frequency is less than AP.38 for a time longer than AP.37
AP.38	PID sleep mode: frequency threshold	... Hz	PID sleep mode is activated when the frequency is less than AP.38 for a time longer than AP.37
AP.39	PID wake up threshold	0-100%	Set the threshold for deactivation of the sleep mode
AP.40	Wake up mode	0-1	0 = below level. PID mode is activated when the feedback variable drops below AP.39 1 = above level. PID mode is activated when the feedback variable rises above AP.39
ACC	Acceleration time	5.0 sec	Insert the value of the acceleration time
dEC	Deceleration time	5.0 sec	Insert the value of the deceleration time

5. MOTOR PARAMETERS


Parameter	Function	Setting	Description
dr.09	Motor control mode	0-4	0 = V/f characteristics 4 = open loop
bA.07	V/f shape	0-3	0 = V/f linear 1 = V/f quadratic 2 = V/f user 3 = V/f quadratic for pumps and fans
bA.10	Nominal frequency	0-1	0 = 60Hz 1 = 50Hz
bA.11	Number of motor poles		Enter the motor number of poles
bA.12	Rated slip speed	_rpm	Set the rated slip speed Calculated as: $fr - (rpm \times P)/120$ Where: fr is the rated frequency rpm is the rated motor rotations P is the number of poles
bA.13	Motor rated current	_A	Set the rated current of the motor
bA.14	Motor no-load current	_A	Set the rated no-load current of the motor
bA.15	Motor nominal voltage	_V	Set the rated voltage of the motor
bA.16	Motor efficiency	_%	Set the motor efficiency (%)
Pr.40	Electronic motor thermal protection	0-2	0 = thermal protection disabled 1 = thermal protection enabled, coast to stop 2 = thermal protection enabled, stop with deceleration ramp

6. ADDITIONAL FUNCTIONS

6.1. Stop mode setting

Parameter	Function	Setting	Description
Ad.08	Motor stop mode (stop)	0	0 = deceleration ramp 1 = DC current braking 2 = free-run 4 = power braking


6.2. Configuration of the relay output function



1842 GB 03 26


Parameter	Function	Setting	Description
OU.31 OU.33	Relay output 1 function Relay output 2 function	29 (default relay 1) 14 (default relay 2)	29 = Fault. The relay switches in case of alarm. 14 = Run. The relay is active as long as the drive is running. 4 = Frequency threshold. The output is activated when the output frequency of the VLG3 is greater than the threshold set in OU.57 (set width OU.58 = 0 Hz) For additional functions, refer to the I747 manual.

6.3. Configuration for the AO analog output function



Parameter	Function	Setting	Description
OU.01	AO analog function	0	0 = Output frequency (10V output is made from the frequency set at dr.20). 1 = Output current (10V output is made from 200% of the driver rated current). 2 = Output voltage 8 = Frequency setpoint. (10V output at the maximum frequency dr.20). For additional functions, refer to the I747 manual.

6.4. Enable of the start at power-up function (AUTOSTART)




1842 GB 03 26

Parameter	Function	Setting	Description
drv	Command source	1, 2	1 = command from terminal block. P1: forward run, P2: reverse run 2 = command from terminal block. P1: run command, P2: reverse direction command
Ad.10	Starting with power on	1	The motor is started automatically when the VLG3 is powered on. It is necessary for the run function to be associated with a digital input, and this must be kept closed to allow automatic restart.
In.65	Multifunction input P1	1	Forward command

WARNING! The activation of this mode causes the automatic restart of the motor at the switching on of the mains voltage of VLG3 variable speed drive. Verify that all the safety requirements are met.

7. COMMON ERROR CODES

Error code	Description	Possible causes	Remedy
	Overload	The load is greater than the motor's rated capacity. The set value for the overload trip level (Pr.21) is too low.	Replace the motor and drive with models that have increased capacity. Increase the set value for the overload trip level.
	Overcurrent	Acc/Dec time is too short, compared to load inertia. The drive load is greater than the rated capacity. The mechanical brake of the motor is operating too fast. A ground fault has occurred in the drive output wiring. The motor insulation is damaged.	Increase Acc/Dec time. Replace the drive with a model that has increased capacity. Check the mechanical brake. Check the output wiring. Replace the motor.
	Overvoltage	Deceleration time is too short for the load inertia. A generative load occurs at the drive output. The input voltage is too high. A ground fault has occurred in the drive output warning. The motor insulation is damaged.	Increase the deceleration time. Use the braking unit. Determine if the input voltage is above the specified value. Check the output wiring. Replace the motor.
	Motor overtemperature	The motor has overheated. The drive load is greater than the rated capacity. The set value for electronic thermal protection is too low. The drive has been operated at too low speed for an extended duration.	Reduce the load or operation frequency. Replace the drive with a mode that has increased capacity. Set an appropriate electronic thermal prevention (ETH) level. Replace the motor with a model that supplies extra power to the cooling fan.
	Power unit overtemperature	There is a problem with the cooling system. The drive cooling fan has been operated for an extended period. The ambient temperature is too high.	Determine if a foreign object is obstructing the air inlet, outlet, or vent. Replace the cooling fan. Keep the ambient temperature below 50°C.