

# INTERFACE PROTECTION SYSTEM UNIT **PMVF90**

for system requiring  
3 maximum  
voltage thresholds



® **Lovato**  
**electric**

ENERGY AND AUTOMATION

# INTERFACE PROTECTION SYSTEM UNIT FOR SYSTEM REQUIRING 3 MAXIMUM VOLTAGE THRESHOLDS

The **PMVF90** device has been designed as an Interface Protection (IP) for system requiring 3 maximum voltage thresholds.




**PMVF90**

| Order code  | Rated voltage |                             |
|---|---------------|-----------------------------|
|   | Control [V]   | Auxiliary [V]               |
| For systems requiring 3 maximum voltage thresholds (E.g.: Czech Republic and Slovakia). |               |                             |
| <b>PMVF90</b>   | Programmable  | 24...240VAC/<br>24...240VDC |

## Display


### PLANT MEASURES



### MAIN MENU - SYNOPTIC



### DIAGNOSTIC - COLLECTION OF STATISTICAL DATA



## Accessories



| Order codes          | Description  |
|----------------------|--|
| Communication ports. |  |
| <b>EXM1010</b>       | Opto-isolated USB interface                                  |
| <b>EXM1011</b>       | Opto-isolated RS232 interface                                |
| <b>EXM1012</b>       | Opto-isolated RS485 interface                                |
| <b>EXM1013</b>       | Opto-isolated Ethernet interface                             |
| <b>EXM1018</b> ①     | IEC/EN 61850 interface                                       |
| Inputs and outputs.  |  |
| <b>EXM1001</b>       | 2 digital opto-isolated inputs and 2 relay outputs 5A 250VAC |
| Modem.               |  |
| <b>EXCGSM01</b>      | Remote control and monitoring GSM modem via SMS              |

#### ① IEC/EN/BS 61850 protocol

The EXP1018 module will be made available only when the competent authorities have established the exact terms of the supervision and control of the specific commands.

## General characteristics

The controls refer to limits of voltage and frequency monitoring. In the case when either the voltage or the frequency are out of admissible limits, the Interface Protection (IP) must step in by de-energising a relay output so that the interface switch (IS) trips.

PMVF90 is equipped with 5 inputs having the following functions:

- IS status feedback
- R.O.C.O.F or Vector shift delay
- Disabling signal
- Remote tripping (forced IS opening, independent of voltage and frequency values)
- Programmable.

Also, there are 3 relay outputs for:

- IS opening and closing
- Backup (programmable)
- Programmable (default: global alarm).

The backup device consists of a signal contemporary or delayed respect to the IS opening command, transmitted only if the IS failed and did not complete the disconnection.

## Operational characteristics

- Auxiliary voltage: 24...240VAC/24...240VDC
- Voltage inputs range: 100-50000VAC (via voltage transformers)
- Relay outputs:  
OUT1: 8A 250VAC, 8A 30VDC  
OUT2: 5A 250VAC, 5A 30VDC  
OUT3: 2A 250VAC, 2A 30VDC
- It can be password protected to prevent parameters being altered
- 5 digital inputs
- Programmable nominal voltage rating, voltage thresholds, frequency and delays
- Support of EXM series communications modules (USB, RS232, RS485, Ethernet)
- Modular housing: 4 modules
- Parameter configuration and remote control (only with communication expansion module) with software **Xpress** and **Synergy**
- Degree of protection: IP40 on front; IP20 on terminals
- Predisposed for IEC/EN 61850 signal supervision using expansion or external module
- Event log (128 events with time reference):
  - interface protection trip events;
  - password interaction events;
  - commands execution;
  - system events.

## Reference standards

Compliant with standards IEC/EN/BS 60255-27; IEC/EN/BS 61010-1, IEC/EN/BS 61000-6-2, IEC/EN/BS 61000-6-4.



## Backup power supply



**PMVFUPS02**


### Compatibility:

- Compatible with contactors (IS or backup function) with standard AC or electronic coil.
- Compatible with undervoltage trip releases (IS or backup function) of moulded case circuit breakers.

## Wiring diagrams


Three-phase connection

LOW VOLTAGE DISTRIBUTION NETWORK




Single-phase connection

LOW VOLTAGE DISTRIBUTION NETWORK




### Connection through VTs in Medium/High Voltage

MEDIUM/HIGH VOLTAGE DISTRIBUTION NETWORK





## Dimensions [mm (in)]

**PMVF90**



**PMVFUPS02**



## General characteristics

Many IP standards require an auxiliary power supply to feed the interface protection (IP), the interface switch (IS) and the backup switch for at least 5 seconds in the event of a power failure. PMVFUPS02 guarantees the necessary energy by accumulating it in capacitors, thus avoiding the use of batteries that require maintenance.

- Power supply: 230VAC, 50Hz
- Output voltage: 230VAC, 50Hz
- Output power: 650VA
- Accumulated energy: 645Ws
- Accumulation time: 60sec
- Modular housing: 9 modules
- Mounting on 35mm DIN rail (IEC/EN/BS 60715) or screw fixing via pull out tabs
- Operating temperature: -5...+50°C
- Degree of protection IP20 on front and terminals.

## Reference standard

Compliant with standards: IEC/EN/BS 61010-1.

## INTERFACE PROTECTION SYSTEM UNIT PMVF90



ENERGY AND AUTOMATION

### LOVATO ELECTRIC S.P.A.

via Don E. Mazza, 12  
24020 Gorle (Bergamo)  
tel +39 035 4282111  
[info@LovatoElectric.com](mailto:info@LovatoElectric.com)

[www.LovatoElectric.com](http://www.LovatoElectric.com)



The products described in this publication are subject to be revised or improved at any moment. Catalogue descriptions and details, such as technical and operational data, drawings, diagrams and instructions, etc., do not have any contractual value. In addition, products should be installed and used by qualified personnel and in compliance with the regulations in force for electrical systems in order to avoid dangers and safety hazards.